HARVIA SAUNA



Instructions for Planning and Installation





Furnish your sauna into an oasis of good feeling

You have chosen Harvia sauna interior: high quality products, aesthetical design and easy installation. Harvia sauna interior consists of cut to length and ready made parts. Please read through the instructions carefully before starting the installation.


Congratulations on a good choice and many enjoyable moments in your new Harvia-sauna!

CONTENTS

Sauna Room Ventilation	3
Cross Section of a Sauna	4
Cross Section of Sauna Wall and Ceiling	4
Panelling	
Installing the Bench Supports	6
FORMULA	7
FORMULA Benches with End Support	9
FORMULA Benches in L-Form	11
Installation of Glass Door	13
Changing the Hanging of a Glass Door	15
Installing the Sauna Lamp	16








SAUNA ROOM VENTILATION

The air in the sauna room should change six times per hour. The figure illustrates different sauna room ventilation options.




- A. Supply air vent location. If mechanical exhaust ventilation is used, place the supply air vent above the heater. If gravity exhaust ventilation is used, place the supply air vent below or next to the heater. The diameter of the supply air pipe must be 50–100 mm. Heater models equipped with separate temperature sensor:

 Do not place the supply air vent so that the air flow cools the temperature sensor (see the temperature sensor installation instructions)!
- B. Exhaust air vent. Place the exhaust air vent near the floor, as far away from the heater as possible.
 The diameter of the exhaust air pipe should be twice the diameter of the supply air pipe.
- C. Optional vent for drying (closed during heating and bathing). The sauna can also be dried by leaving the door open after bathing.
- D. If the exhaust air vent is in the washroom, the gap underneath the sauna door must be at least 100 mm. Mechanical exhaust ventilation is mandatory.


CROSS SECTION OF A SAUNA


Vertical panelling. Drawing is indicative.



CROSS SECTION OF SAUNA WALL AND CEILING

Drawings are indicative.






PANELLING

1.

- A. Frame and insulation
- B. Frame and insulation for ceiling
- C. Option: cement board
- D. Underlayment board for tiles (water insulation is lifted against the board)
- E. Aluminium paper


2.

- A. Ventilation laths for ceiling
- B. Horizontal ventilation laths



Use aluminium tape on the seams of aluminium paper. Overlap the aluminium paper excessively. Tape the lower end of aluminium paper to the underlayment board/upper end of tiles or to the water insulation.

Install aluminium paper also to the ceiling. Be sure to tape all seams.




3.


- A. Reinforcements for bench supports
- B. Ceiling panel boards

4.

Wall panel boards

If the sauna is equipped with a color light system, drill a hole for the wiring of the color light device ca. 50 mm above the (planned) top surface of the upper bench.






INSTALLING THE BENCH SUPPORTS


- 1. Measure and mark the heights for the bench supports. If you have benches with an end support, it is easy to check and mark the height by using the end support.
- 2. Fasten the supplied plywood pieces behind the bench supports.
- 3. Fasten the bench supports to the wall.


ATTENTION! Bench heights: Upper bench from the floor – 900 mm Lower bench from the floor – 450 mm

In Special Saunas the heights for the benches must be checked from the drawings sent with your sauna set. As a rule, the supports are installed 120 mm lower than the actual bench height.





FORMULA







3.







FORMULA BENCHES WITH END SUPPORT









FORMULA BENCHES IN L-FORM



2.






INSTALLATION OF GLASS DOOR

Note! If the material in the walls is porous, check the right methods of installing and sealing from your dealer!


- 1. Place a piece of cardboard or similar padding under the door to prevent the door from hitting the floor during installation. A tempered glass door can break into small pieces as a result of a sharp hit. NOTE! The support in the bottom edge of the door frame should be kept in its place until installation is finished!
- 2. Measure the width and height of the opening and the door.

	Size of glass door	Width of opening
	7 x 19 – 7 x 21	min. 700 mm
	8 x 19 – 8 x 21	min. 800 mm
	9 x 19 – 9 x 21	min. 900 mm
	10 x 19 - 10 x 21	min. 1000 mm


3. Install supports on the sides of the opening. Remember to leave room for wedging on both sides of the opening. Install the supports vertically in-line using a spirit level. A straight board can be used as an extension for a short spirit level. Cut and install supports made of e.g. pieces of wood under the door.




4. Leave a gap of about 10 mm between the top of the frame and the opening. Leave a gap of max. 25 mm under the door.




Tip! You can make the installation easier by installing temporary stoppers to the supports so that the door can lean on them. This is especially recommended if you are working alone. To be able to install the cornice strips correctly, place the stoppers so that the flagging on the wall and the door frame are on the same level.



5. Lift the glass door into the opening and place wegdes next to bores between the supports. Make sure the wedges are not placed under the bores. Fasten the hinge-side part of the frame to wall with screws (topmost screw first). Next, wedge and fasten the opposite side in the same way. To make sure the frame is installed in the right position, check that the gap between the glass and the frame is equally wide from bottom to top (above the door also).



6. After fastening the frame with screws, check that the frame is straight and the door opens and closes properly. Cut off the excess parts of the wedges if necessary (saw in a vertical position). Remove supports from under the door and from the bottom edge of the frame. Install the cornice strips and the handle. Finally, loosen the roller latch to prevent the door from locking itself when the door is closed the first time.






Tip! Coat the lower ends of the frame woods, cornice strips and visible parts of the frame with sauna protection before installing the cornice strips.


CHANGING THE HANGING OF A GLASS DOOR

1. Remove the glass element from the hinges (patterned glass only).




- Unfasten the four screws which lock the door frame head.
- 3. Remove the door frame head.

4. Turn the vertical parts of the frame as shown in the diagram. The hinge part is fitted in the position of the ring lock and vice versa.





5. Fasten the four screws that were unfastened in step 2.





INSTALLING THE SAUNA LAMP


Only a professional electrician is allowed to install the lamp. Use only light sources and rated wattages as marked in the luminaire. Switch off the current before installation or service. This installation instruction must be kept available for future maintenance.























HARVIA

Harvia Sauna
PL38
40951 Muurame
Finland
www.harviasauna.com